

Exercise 2: Bike Frame Analysis

This exercise will analyze a new, innovative mountain bike frame design under structural loads. The objective is to determine the maximum stresses in the frame due to the weight of a large rider for 3 different loading conditions. The model has already been sufficiently defeatured to facilitate building the finite element model. The exercise will use the no defeature/repair option during the Parasolid import. Shell elements will be used and a ½ symmetry model will be meshed using the Mechanical Toolbar (MTB). Symmetry boundary conditions and loads will also be applied in the MTB, along with the built-in properties for Titanium.

Important: Please Read the Following

This exercise contains the step by step instructions to complete the problem described above. All instructions to the exercise are denoted by **Blue** colored text.

This exercise also contains detailed information about the functions on Mechanical Toolbar. The information that is provided covers the required functions necessary to complete this exercise. Other functions will be covered in later exercises. The information should be read before proceeding with the instructions. The detailed information is denoted by the **Black** colored text.





Outline:

- 1. Launch ANSYS/Professional
 - 1.1. Launch ANSYS using start menu.
 - **1.2. Activate the Mechanical Toolbar.**
- 2. Setup
 - 2.1. Setting the Analysis Type.
- 3. Model
 - 3.1. Model Import
 - 3.2. Shell Properties
 - 3.3. Viewing the Model
 - 3.4. Defining Shell Or 2-D Solid Shapes
 - 3.5. Assign Shape
 - 3.6. Assigning Shell Properties to The Model
 - 3.7. Assigning Other Shell Properties to The Model
 - 3.8. Assign Material Properties To The Model
 - 3.9. Meshing Using Smartsizing
- 4. Loads And Boundary Conditions
 - 4.1. Applying Boundary Constraints To The Model
 - 4.2. Create The Symmetry Boundary Constraints.
 - 4.3. Renaming Environments
 - 4.4. Copying Environments
 - 4.5. Creating Loads For Combo Environment
 - 4.6. Creating Loads For Standing Environment
 - 4.7. Creating Loads For Sitting Environment
 - 4.8. Save the Model
- 5. Solve Linear Elastic Solution
 - 5.1. Solving With Multiple Environments
- 6. Linear Elastic Solution Results
 - 6.1. Post Processing
 - 6.2. Complete the following
 - 6.3. Finding areas of maximum
 - 6.4. Complete the following
 - 6.5. Animate the Results



- 6.6. Create a Report
- 7. Review
 - 7.1. Review Problem
- 8. Conclusion



Step-by-step Instructions:

Before beginning this problem, create a separate folder on your computer for this job and copy the bike parasolid file **bike.xmt_txt** to this folder.

If you do not have a parasolid translator, copy the file **bike.db** instead. When you reach section 3.1 (Model Import), select **ANSYS** (*db*) for type of file and import the bike.db file.

1. Launch ANSYS/Professional

1.1. Launch ANSYS using start menu.

- A. Browse to select the working directory you just created for this job.
- B. Change the Graphics device name to 3D
- C. Enter **bike** for the *Initial jobname*. All ANSYS files created for this problem will have a filename of **bike** followed by a unique extension.
- D. Change the *Memory Requested* for Total Workspace and for **Database** sizes for this job to be **256** and **64** respectively.

E. Click **RUN** to start the ANSYS GUI.

The following step is required only if you are **not** running ANSYS Professional.

📣 Intera	active 5.6	
	Product selection	ANSYS/Mechanical U
W	orking directory	j:\ansys\bike
Gr	aphics device name	□ <u>□</u> 1.1.B
Ini	tial jobname	bike 1.1.C
M	emory requested (megabyte	25)
	for Total Workspace	256
	for Database	64
Re	ead START.ANS file at star	rt-up? Yes
GL	JI configuration	
Pa	arameters to be defined (-par1 val1 -par2 val2)	,
La	nguage Selection	[english]
E>	ecute a customized ANSY	S executable
F	lun Close	Reset Cancel About

Exercise 2: Bike Frame Analysis



The following step is required only if you are **not** running ANSYS Professional.

1.2. Activate the Mechanical Toolbar (MTB)

- A. Click on MenuCtrls.
- B. Click on **Mechanical Toolbar.** The Mechanical Toolbar (MTB) will now appear and replace the Main Menu, Input Window, and the Toolbar.

🐼 ANSYS/Mechanical U Utility Menu	
<u>File Select List Plot PlotCtrls WorkPlane Parameters Macro</u>	MenuCtris 1.2.A
ANSYS Input	✓ Main Menu ANSYS Toolbar 🕅
	V Input Window
	Graphics Window
	✓ Toolbar
Pick a menu item or enter ANSYS command bel	Mechanical Toolbar 1.2.B
	Undate Toolbar
	Edit Toolbar
	Save Toolbar
	Bestore Toolbar
	Message Controls
	Save Menu Layout

2. Setup

- 2.1. Setting the Analysis Type. In the Mechanical Toolbar (MTB), let's set the basic analysis type options.
 - A. Set the Engineering Discipline to Structural.
 - B. Set the Analysis Type to Static.
 - C. Set the Unit System to m-kg-s-°C.
 - D. Type in **Bike Analysis** for the *Graphic Title* for the analysis.
 - E. This step is optional. Click on the **Toolbar Properties** button. The Toolbar Properties dialog will appear.

AMOVE Hard Tool Stars Shikeb			_ 🗆 ×
se 2.1.A Load S 2.1.B 2.1.C	2.1.D	2.1.E	□ 🛋 🖬 🖇 📟 🚳
Structural Static m-kg-s-°C	Bike Analysis		
📕 🚱 🛱 🕅 🔣	_		
Str	uctural Static	m-kg-s-°C	



F. Click on the **User Info** tab.

Toolbar Properties General User Info 2.1.F Start Configuration *ABBR Toolbar Input Window Resize graphics window	System Utilities Calculator Calc Editor Inotepad Enable PS print
ОК	Cancel Help

- G. Enter your Name, Company, and Address.
- H. Click **OK** when finished.

3.

Toolbar Prope	rties D		
General Use	er Info About		
Name	Brad Davis		
Company	ADI Custom Training 2.1.G		
Address	PO Box 958 Hobe Sound, FL 33475		
2.1.H	OK Cancel Help		



Model

3.1. Model Import: Under the Model tab, we import the geometry file, assign shell element thickness, material properties, and mesh the part.

A. Click on the **Model** tab in the MTB.

🚯 ANSYS Mechanical Toolbar - j:	\ansys\bike\bike.c	lb			
Setup Model 3.1.A	Results				□ 🛎 🖬 🤋 📟 🚳
≝ 3.1.B 💌 🕅	500 J	× 8	, µ , , , , c	<u>×</u>	
	terial coloring] 📕 🎒			
		Structural	Static	m-kg-s-°C	

B. Click on the **Import geometry** button to bring up the *Model Import* dialog.

C. Change the Files of type: option to Parasolid.

Import Geom	etry - Select File		? ×	
Look <u>i</u> n:	🔄 bike 💽 3. 1	I.D		
🔊 bike.xmt_t	xt < 3.1.E			
File <u>n</u> ame:		ΙΓ	<u>O</u> pen	3.1.F
Files of <u>type</u> :	Parasolid (*.x*_*t)	1	Cancel	
	IGES (*.ig*s)	<u> </u>		
	ANSYS (*.db*) Parasolid (*.x* *t) 3.1.C			
	SAT (not licensed) (*-NL-)			
	UG (not licensed) (*-NL-)			

- D. Change the Look in: directory to the directory containing the bike parasolid (bike)
- E. In the file list, highlight the file named **bike.xmt_txt**.
- F. Click Open.

Note: If you do not have a parasolid translator, copy the file **bike.db** instead. When you reach section 3.1 (Model Import), select **ANSYS** (*db*) for type of file and import the bike.db file.



The Import Geometry - Select Import Method dialog will appear Select Shell or 2-D Solid.

Import Geometry - Select Import Method 🛛 🔀
You must identify the type of geometry on the Parasolid file
Shell or 2-D Solid < 3.1.G
$_{\square}$ You must decide if you want to cle <u>an-up the mo</u> del if the import fails $_{\square}$
No model clean-up (faster) 3.1.H
C Allow model clean-up and defeaturing
OK 3.1.I Help

- G. Leave the No model clean-up (faster) option set.
- H. Click **OK**. This may take a few seconds. Since you are importing a shell area (surface) model The *Shell Properties* dialog will appear. In this dialog you are asked to input the shell properties.

Shell Properti	es 🗴
Name	
Thickness	
OK	Help

3.2. Shell Properties

When importing a Shell or 2-D Solid, the Shell Properties dialog box will next appear to allow you to define the default property name and thickness for the model. Input a name and the shell element thickness in this dialog.

Shell Properties		×
Name	1mm thick	
Thickness	.001	3.2.A
01	3.2.B	

- A. Input 1mm thick for the Name and .001 for the Thickness.
- B. Click **OK**. ANSYS will now import the Parasolid file and draw the part in the graphics window.





C. Use the dynamic viewing controls to inspect the model. Select the **Pan-Zoom-Rotate** button. If you are unfamiliar with the dynamic viewing controls, read the following pages.

🚯 ANSYS Mechanical Toolbar - J:\ansys\bike\bike.db	
Setup Model Load Solve Results	
🛃 1mm thick 💌 🔟 Aluminum 💌 😣 🗏 🔣	
I al coloring I A B	
Structural Static m-kg-s-*C	



3.3. Viewing the model

There are several buttons on the Mechanical Toolbar that allow you to manipulate graphic plots. These buttons and their functions include:

🖓 ANSYS Mechanical Toolbar - J:\ansys\bike\bike.db 📃 🗌 🗵
Setup Model Load Solve Results
Imm thick Imm thick <t< th=""></t<>
Image: Second
Structural Static m-kg-s-°C
• Plot : To access a fly-out toolbar of plotting options, do the following:
 Position the cursor on the Plot button.
 Press and hold the left mouse button until the fly-out toolbar appears.
 The fly-out toolbar contains the following buttons: Keypoint Plot, Line Plot, Area Plot, Volume Plot, Node Plot, and Element Plot.
 Release the left mouse button.
 Position the cursor on the desired fly-out button and click.
• Oblique View: Sets the view of the graphic window to oblique.
• View: Sets the view of the graphic window. To access a fly-out toolbar:
 Position the cursor on the View button.
 Press and hold the left mouse button until the fly-out toolbar appears.
 The fly-out toolbar contains the following View option buttons: Top View, Bottom View, Front View, Back View, Left View, Right View, Oblique View, Working Plane View, and Isometric View.



- Pan-Zoom-Rotate: This option activates the Pan-Zoom-Rotate control, which allows you manipulate the model view by panning, zooming, or rotating the model. Note: This is a good option to leave on while working on the model.
 - To change the view, click on the desired view button (Top, Front, Iso, etc)
 - You can choose a Zoom method. Your options include: Zoom, Box Zoom, Win Zoom, and Back Up (UnZoom).
 - Pan/Zoom buttons: Pan up/down left/right using the arrows. Small dot zooms out and the large dot zooms in. The **Rate** slider located below the rotate buttons controls the amount of change in model size from zooming in or out.
 - The **Rotate** buttons allow you to define the axis of rotation. The rate slider that is below the rotate buttons controls the amount of rotation.
 - **Dynamic Mode**: This option allows you to use your mouse buttons to pan/zoom/rotate. When this is on, the left mouse button pans, the middle mouse button zooms, and the right mouse button rotates.
 - Lighting: This option allows you to control the light source location, intensity, and the reflectance of your model. When this option is ON the mouse buttons function as follows: Left Button: Move in X-direction to increase or decrease the reflectance of your model. Move in the Y-direction to change the intensity of the directional lights (there are two directional lights, one in front and one behind your model). Middle Button: Move in the X-direction to rotate the directional lights about the screen Z-axis. Move in the Y-direction to change



the intensity of the ambient light. Right Button: Move in the Xdirection to rotate the directional lights about the screen Y-axis. Move in the Y-direction to rotate the lights about the screen X-axis.

- Fit: Automatically adjusts that amount of zoom in the active window so that your entire model can be seen within the window.
- **Reset**: Removes any Pan-Zoom-Rotate changes in the active window. Your model will be displayed in its default orientation and sized to fit within the active widow.
- Close: Dismisses the Pan-Zoom-Rotate dialog box.



- Alternatives to using the Pan-Zoom-Rotate control :
 - **Pan** Hold down the **CTRL** key and press the left mouse button. Move the mouse left, right, up, or down to move the model in the desired direction.
 - Zoom Hold down the CTRL key and press the middle mouse button. Move the mouse up to zoom in. Move the mouse down to zoom out. If you are using a two-button mouse, you may be able to mimic the action of a middle mouse button by holding down the SHIFT key and pressing the right mouse button.
 - Rotate about Z axis Hold down the CTRL key and press the middle mouse button. Move the mouse left or right to rotate the model about the Z axis. If you are using a two-button mouse, you may be able to mimic the action of a middle mouse button by holding down the CTRL-SHIFT key and pressing the right mouse button.
 - Rotate about X or Y axis—Hold down the CTRL key and press the right mouse button. Move the mouse to rotate the model about the X (up/down) or Y (left/right) axis.
- **Redraw Model**: Redraws (refreshes) the contents of the graphic window.
 - **Render Model**: This option allows you to set the render options for the model. The render options include material coloring, material texturing, thickness, translucency, wireframe, gray scale, and show edges.



- Boundary Conditions: Toggles boundary condition symbols on and off.
- Print Hardcopy: Prints a hardcopy of the graphic window contents.
- A. Select the Pan-Zoom-Rotate button.
- B. Thoroughly inspect the model by Panning, zooming, and rotating the model. Play with the light source option.
- C. Return the view to **Oblique** when you are finished. Leave the Pan-Zoom-Rotate control open for the rest of the exercise



3.4. Defining Shell or 2-D Solid Shapes

To define element shapes for a model, click on the **Default Shape** drop down list and choose an element shape that you want to use.

All of the element shapes listed below are available in the Mechanical Toolbar. However, the choices that appear in the Default Shape drop down list box during a particular analysis will vary depending on the characteristics of the model that you imported.

🚯 ANSYS Mechanical Tool	lbar - J:\ansys\bike\bike.db	
Setup Model Load S	Solve Results	
Imm Thick Shell	▼ 🗹 Aluminum 🔽 😣	
Plane Stress Plane Strain Axisymmetric	Material coloring	
	Structural Static m-kg-s-°C	

Shell

Used to model thin structures in 3-D space. Can also be used for 2-D representations of such structures.

Solid

Used to model thick structures in 3-D space.

Plane Stress

Used to model thin planar structures in 2-D space.

Plane Strain

Used to model "infinitely long" structures having a constant cross-section in 2-D space.

Axisymmetric

Used to model solid structures with an axis of rotational symmetry in 2-D space.



3.5. Assign Shape

if you have more than one shape in the model, select an element shape from the *Default Shape* drop down list and assign the shape to entities in the model.

🚯 ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
Setup Model Load Solve Results	□ 🛩 🖬 🤋 📟 🚳
Pefault Shape 💌 🗹 Aluminum 💌 😣 🗏 💷 📧	
🔀 🔂 🗇 🔣 Material coloring 🔽 🖂 🎒	
Structural Static m-kg-s-°C	

When you choose **Shell** in the *Default Shape* drop down list, the Shell Properties dialog box appears.

Shell Properties 🛛 🗙			×
Name			
Thickness			
Ok	<	Help	

- In the **Name** text entry box, type a unique name to identify this shell. It is useful to include the thickness of the shell in the name.
- In the **Thickness** text entry box, type the thickness of this shell.
- Click **OK**. The name of the defined shell shape will appear in the Default Shape drop down list.

You can view (but not change) the Name and Thickness properties of a shape by right-clicking in the Default Shape drop down list box and then selecting **Properties**.

A. Create another shell property. Click on the *Default Shape* window and highlight **Shell**. The *Shell Properties* dialog will appear.

🚯 ANSY	'S Mechanical T	oolbar - j:\ansys\	\bike\bike.db				
Setup	Model Load	Solve Results	_	Shell Prop	erties		💌 🖻 🖪 🤶 📟 🚳
ß	1mm thick Shell	<u> </u>	hinum [Name	2mm thick	_	
	1mm thick	 Material colo	ring 🔽	Thickness	.002 3.5.B		
				OK	3.5.C	Help	
		•					

B. Input the name **2mm thick** and .002 (meters) for the thickness.

C. Click OK.



3.6. Assign the 1mm thick shape property to the model.

A. Click on the Default Shape window and pick the 1mm thick property





3.7. Assign the 2mm thick shape property to the areas shown

A. Click on the *Render Model drop down list* and pick **Wireframe** to better facilitate the next picking sequence.



- B. Click on the **Default Shape** window and pick the **2mm thick** property.
- C. Click on the **Assign Shape** button. The picker will appear.
 - D. Refer to the diagram to the right. Zoom up on Area **A**:





E. Pick the 3 highlighted areas shown below.

Tips for selecting areas: If you click and hold the left mouse button while dragging across the screen, each area to be selected will be highlighted. The area is not actually selected until you release the button. The hot spot for each area is the geometric center, which may not even lie on that area if it is a curved surface like the fillets. You can use the dynamic viewing controls to obtain a better orientation for selecting each area during the selection process. If you accidentally select a wrong area, click the right mouse button. The cursor will change from an upward pointing arrow to a downward pointing arrow indicating that you can now unpick items from the selection with the left mouse button. Click the right button again to toggle back to picking. When you have selected all the areas, click OK.



F. Select Fit on the Pan-Zoom-Rotate control dialog to see the whole bike.





I. Refer to the diagram. Zoom up on Area C:

J. Pick the 2 highlighted areas shown below. Fit the view when finished





- K. Refer to the diagram. Zoom up on Area B:
- L. Change the picker option to Box
- M. Enclose the rear axle attachment with a selection box as shown below. Check the *Count* in the Picker dialog. You should have **24** picked areas



N. Select **OK** in the picker and then **Fit** the model. Notice the color coding between the 2 shell properties.





3.8. Assign Material Properties

A. Now we want to assign the material properties to the entire model. Click on the Assign Material button. The Material for Assignment dialog will appear

🚯 ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
Setup Model Load Solve Results	
🔨 🗗 🗐 💢 Wireframe 🗹 🖂 🎒	
Structural Static	m·kg·s·°C
 B. ANSYS has built in properties for Aluminum, Steel and Titanium. Highlight Titanium in the list. C. Click Continue. The picker will appear. D. Click the Pick all button 	Material for Assignment X Aluminum Steel <u>Titanium</u> 3.8.B
E. The model rendering will automatically change to Material Coloring and the legend will indicate that the entire part is Titanium.	Continue 3.8.C
ANSYS Graphics APLOT type=1 mat=2 real=2 csys=0	
	ARICIZO





3.9. Meshing: We will use the default SmartSize meshing to create a mesh on the part

A. The slider bar in the MTB controls the SmartSize mesh density in various levels from very fine (left most setting) to very course (right most setting). Set the slider bar to the 6th notch.





4. Loads and Boundary Conditions

Now that we have completed the model definition phase, it's time to apply the loads and boundary conditions. 3 different environments will be created with the same boundary conditions but different loads. The first load environment will be the entire weight of the rider on the seat. The second load environment will be the entire weight of the rider on the pedals and the third load environment will be the weight of the rider distributed on the seat, pedals, and handlebars.

ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
4.1.A Load Solve Results	□ 🛩 🖬 💡 📟 🚳
Environment 1 4.1.B	
Structural Static m-kg-s-*C	

4.1. Apply the boundary constraints to the model

- A. Click on the **Load** tab in the MTB. Notice that the current environment is **Environment 1**.
- H X B. Make sure the Add button is depressed.
 - C. Change the *Render Model* to **Wireframe** to aid in picking the correct areas.
 - D. Change the display to an isometric view. Select **ISO** on the Pan-Zoom-Rotate dialog.







E. Click and hold the cursor on the **Constraint** button to get the fly-out toolbar.



F. Click on Constrain Area. The Picker dialog will appear.

G. Refer to the diagram below. Zoom up on area A





H. Pick the face on the rear wheel axle mount as shown. **Fit** the View when finished.



- I. Refer to the diagram. Zoom up on area B.
- J. Pick the end face on the front fork as shown. Fit the view when finished.



K. Click on **OK** on the Picker. The *Constrain area* dialog will appear.



L. Check on the constraints for **Y direction**, **Z direction**. These constraints will keep these areas from moving up/down and inward/outward but will allow movement forward/backward.



- M. Click **OK** and then **Fit** the view. The constraint symbols will appear.
- N. If the constraint symbols did not appear, you may need to click on the **Boundary Condition** Button.

🚯 ANSYS Mechanical Toolbar - J:\ansys\bike\a.db	
Setup Model Load Solve Results	D 🖻 🖬 🤋 🕽 🚳
Environment 1 🔄 🕂 🗙 🙈 📃 🔩 🖳 🏹 🖸	
【● □ ● ▼ ▼ ▼ ▼ ●	
Structural Static m-kg-s-°C	





O. Click on Area Constraint. The picker will appear.



P. Refer to the diagram and then Zoom up on area C .



Q. Pick the 2 faces as shown.

R. Click **OK** on the picker dialog. The Constrain Area dialog will appear.



S. Check **ON** the motion constraint for **X direction** and click **OFF** the motion constraints for **Y direction** and **Z direction**

	Constrain Area		×
4.1.S	Motion K direction Y direction Z direction	Rotation about X axis about Y axis about Z axis	Plane out of plane
	Coordinate System G	lobal Cartesian	▼ Help

- T. Click OK.
- U. **Fit** the view. The constraint symbols will appear. This will hold the model from translating in the X-direction and prevent rigid body motion.





4.2. Create the Symmetry boundary conditions

A. Change the view to a Right view. Click and hold on the **View** button to get the fly out toolbar.

🚸 ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
Setup Model Load Solve Results	D 😂 🖬 💡 📟 🚳
Structural Static m-kg-s-°C	

B. Pick the **Right view** option. The view should look as shown below.

ANSYS Graphics APLOT typ	e=1 mat=2 real=3 csys=0	
	8	ANSYS
	Â	
	M-H	
Bike Analysis		

C. Click on the **Model Symmetry** button. The Picker will appear.

🔞 ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
Setup Model Load Solve Results	
Environment 1	
🔀 🔂 🚳 🔀 Wireframe 🗹 🖂 🎒	
Structural Static m-kg-s-*C	



D. Change the picker option to **Box.** Let's pick only the edges on the symmetry plane. This may be a little tricky, so we will do this in 2 steps.



- E. Create a selection box as shown. Make sure that the edges on the symmetry plane are enclosed.
- F. Click OK. Little "S" symbols will appear indicating symmetry.



Exercise 2: Bike Frame Analysis



- G. If you were to inspect the model, you might find that a few extra lines might have been selected in the picking process. Therefore we need to delete these symmetry boundary conditions.
- H. Click on **Delete B.C**.
- I. Click on the **Model Symmetry** button. The Picker will appear
- J. Change the picker option to **Box.**
- K. Create a selection box as shown below. Make sure that the edges on the symmetry plane are **not** enclosed.





L. Click **OK** on the Picker. Inspect the model. Make sure the "S" symbol is only on edges on the plane of symmetry





4.3. Rename Environment 1

- A. Click in the Load Environment window to get the drop down list.
- B. Pick **Rename Environment**. You want to use descriptive names.

🚜 ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
Setup Model Load Solve Results	
Environment 1 4.3.A	
Delete Environment Hename Environment 4.3.B	
Structural Static m-kg-s-*C	

C. The Rename Environment dialog will appear. Input **Sitting** in the *To* window. The sitting environment will simulate the riders weight (1424 N or 320 lbs) fully on the seat.

Renar	ne Environment		×
From	Environment 1	•	
To	Sitting	4.3.	В
	ок 4.3.С	el	Help

D. Click OK.

- 4.4. Make 2 copies of the current Boundary Condition so that we may use the same BC's for the different loading conditions.
 - A. Click in the **Load Environment** window to get the drop down list.
 - B. Pick **Copy Environment**. The *Copy Environment* dialog will appear.

🚯 ANSYS Mechanical Toolbar - j:\ansys\bike\bike.db	
Setup Model Load Solve Results Environment 1 4.4.A A A A	
New Environment 4.4.B Copy Environment 4.4.B	
Structural Static m-kg-s-°C	



C. Input **Standing** in the *To* window. The standing environment will simulate the rider's weight fully on the pedals.



- D. Click OK. You now have a copy of the original boundary conditions.
- E. Click in Load Environment window again to get the drop down list.
- F. Pick Copy Environment. The Copy Environment dialog will appear.

🚜 ANSYS Mechanical Toolbar - J:\ansys\bike\a.db	
Setup Model Load Solve Results	D 🖻 🖬 🤋 📟 🚳
Standing 4.4.E	
New Environment 4.4.F	
Structural Static m-kg-s-*C	

G. Input **Combo** in the *To* window. The Combo environment will simulate the rider's weight distributed on the pedals, seat, and handlebars.

Copy Environment	×
From Standing	
To Combd 4.4.G	
OK 4.4.H Help	

- H. Click **OK**. You now have 2 copies of the original boundary condition.
- I. Turn OFF the boundary conditions display to aid in picking for the next step. Click on **Boundary Conditions.**

🚜 ANSYS Mechanical Toolbar - J:\ansys\bike\bike.db	
Setup Model Load Solve Results	
Structural Static m-kg-s-°C	



4.5. Create the Loads for the Combo environment.

A. Make sure that **Combo** is the current environment and the **Add** button is depressed Pan-Zoom-Rotate



- B. Change the view to the **ISO View** and the **Render** to **Wireframe** to better facilitate the load application.
- C. Click and hold the left mouse button on **Force** to get the fly out toolbar.
- D. Click on Area force. The Picker dialog will appear.

🚯 ANSYS Mechanical Toolbar - J:\ansys\bike\a.dt	
Setup Model Load Solve Results 4.5.C	□ 🛩 🖬 🖇 💭
Structural Static m-kg-s-°C	



E. Refer to the diagram above, and zoom up on Area A.





F. Pick the highlighted area as shown. **Fit** the view when finished

G. Refer to the diagram and zoom up on area B.



H. Pick the highlighted area as shown. **Fit** the view when finished.



I. Refer to the diagram and zoom up on area C.



- J. Select the highlighted area as shown.
- K. Click **OK** on the picker dialog. The *Total Force on Area* dialog will appear.



- L. Input **-712** (Newtons) for Force along the *Y*-axis. Since this is a symmetrical model the total load of 1424 N was divided in half.
- M. Click **OK** to apply the load.
- N. Fit the view to see the entire model



O. Click on the **Boundary Conditions** button to see the applied load symbols.





P. Click on the **Boundary Conditions** button again to hide the loads and BC's.



4.6. Create the Loads for the Standing environment.

A. Click in the Load Environment window to get the drop down list.

B. Pick the **Standing** environment.



- C. Click on Area force. The Picker dialog will appear.
- D. Refer to the diagram and zoom up on area B.



E. Pick the highlighted area as shown.

F. Click **OK** in the picker. The **Total Force on Area** dialog will appear.



G. Input -712 (Newtons) for Force along the Y-axis.



H. Click **OK**. **Fit** the view.

I. Click on the **Boundary Conditions** button to see the applied load.

🚜 ANSYS Mechanical Toolbar - J:\ansys\bike\a.db	
Setup Model Load Solve Results	□ 🛩 🖬 💡 🕽 🚳
Standing 🗾 🕂 🗙 🙈 📃 🗸 🖷 🖳 Ϋ 🖸	
民 (1) Wireframe 民 (Wireframe 民 (1) Wireframe 民 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	
Structural Static m-kg-s-°C	



J. Click on the **Boundary Conditions** button again to hide the loads and BC's.



4.7. Create the Loads for the Sitting Environment.

- A. Click in the **Load Environment** window to get the drop down list.
- B. Pick the **Sitting** environment.
- C. Click on Area force. The Picker dialog will appear.

🚯 ANSYS Mechanical Toolbar - J:\ansys\bike\bike.db		
Setup Model Load Solve Results		
	ę 🛛	
Standing Sitting A.7.B rame		
Structural	Static m-kg-s-*C	

D. Refer to the diagram and zoom up on area A.





- E. Pick the highlighted area as shown.
- F. Click OK in the picker. The Total Force on Area dialog will appear.
- G. Input -712 (Newtons) for Force along the Y-axis.
- H. Click **OK** and then **Fit** the view.





I. Click on the **Boundary Conditions** button to see the applied load.







4.8. Now is a good time to save the model.

- A. Click on the **Save** button. The Save As dialog will appear.
- B. Input the name **Bike**.
- C. Select Save.

🚜 ANSYS Mechanical Toolbar - J:\ansys\bike\a.db	
Setup Model Load Solve Results	□ 🖻 🛋 4.8.A 🗕
Siting	
Structural Static m-kg-s-*C	

Savejn: 🔄 bike 💽 🗈 📸 📰	
en report1	
Bike.db	
i clean.db Mtsetup.db	
File name: bike 4.8.B Save 4.8.C	
Save as type: ANSYS (*.db)	



_

5. Solve Linear Elastic Solution:

5.1. We are ready to solve the model with the 3 environments

ANSYS Mechanical 5.1.A ansys\bike\bike.db	
Setup Model Load Solve Results Solve now Solve Solve Solve	
Structural Static m-kg-s-*C	

- A. Click on the **Solve** tab in the MTB.
- B. Click on the **Solve Problem** button. The Solve Environment(s) dialog will appear.

Solve En	vironment(s)	×
Environ	nment(s) to Solve	
Sitting Standin	5.1.C	
Combo	3	
пк	51D	Help
	0.1.0	

- C. Select all 3 environments to solve.
- D. Click **OK.** The solving process will take a few moments. Please be patient.
- E. When finished, a text window will appear showing that the solution completed and will list the maximum displacement and stress. Close this box when finished reviewing. Also, a von Mises stress plot for the first environment will appear.

🐼 summary.txt					×	5.1
Eile						\sim
		Maximum Displacement		Maxin Equiv Si	mum tress	
Environment Name	Solve OK?	(m)	(Pa)	
Sitting	Yes	0.1057	2E-01	0.4369	5E+09	
Standing	Yes	0.6649	5E-03	0.3119	6E+09	
Combo	Yes	0.2353	9E-02	0.3485	4E+09	







6. Linear Elastic Results:

6.1. We are ready for the post-processing phase.

A. Click on the **Results** tab.

ANSYS Mechanical Toolbar 6.1.A ike\bike.db	
Setup Model Load Solve Results	
Sitting 6.1.C Equivalent Stress 6.1.D = 4 = 6	
💢 🔁 🗗 🐼 Show edges 🗾 📇 🎒	
Structural Static m-kg-s-°C	

- B. The von Mises stress should already be displayed. Use the pan/zoom/rotate function to review all portions of the model. Other components of stress as well as displacement can be plotted.
- C. Change the Results Item to be shown from Equivalent Stress to 1st **Principal Stress**.



D. Click the Plot Results button.



E. You can also look at the different environments. Click on the *Load Environment* drop down list and pick **Standing**. The system will display the Equivalent Stress plot for the Standing environment.





Complete the following:

- F. Determine which environment has the highest Equivalent stress.
- G. Are there any stresses above the yield strength of Titanium (825Mpa)?



6.2. Find the area of maximum stress

A. Plot the results for Equivalent stress for the Sitting environment. Set the Environment to **Sitting.**





- D. Change the *Results Item* to **Displaced Shape**.
- E. Click on the **Plot Results** button. The Displacement Shape plot will appear. The displacements are small in comparison to the thickness of the model indicating good compliance with Shell element theory.





Complete the following:

F. Which loading environment produces the greatest displacement?





6.3. Animate the results.

A. Click on the arrow next to the Animate button.

🚯 ANSYS Mechanical Toolbar - J:\ansys\bike\a.db	
Setup Model Load Solve Results	
Sitting Displaced Shape 6.3.C	2€ < 6.3.A
	2 4 6 8 6.3.B
🔀 🔂 🗇 🔀 Show edges 🗾 💾 🎒	10 15 20 25
Select to animate the result item Structural	kg-sx*C

- B. Change the number of frames to 8.
- C. Click on the **Animate** button to start the animation.
- D. Click on **Close** when you are satisfied.





6.4. Create a Report

A. Click on the **Show Report** button

🚸 ANSYS Mechanical Toolbar - J:\ansys\axle\axle2.db	
Setup Model Load Solve Results	□ ☞ 🖬 💡 📟 🚳
Environment 1 🔽 Displaced Shape	
📕 🚱 🔂 🗐 🔣 Show edges 🔽 📕 🚭	
Structural Static inch-lbm-s-°F	

B. Toggle ON the Create a new report options and click on General Report

	🚯 Report Options 📃 🗖 🗙
	HTML Report Options
6.4.B	© Create a new report General Report User Defined
	C View an existing report
	OK 6.4.C Help

- C. Click **OK.** The report generation may take a few minutes. ANSYS will generate a professional looking report summarizing the model definition including element type, number of nodes and elements, applied loads, and constraints. All stresses, displacements, and reaction force components will be plotted and summarized as well.
- D. When complete, ANSYS will launch the report in your Internet browser. Take a few moments to review each section. This report can be customized and included in other documentation by cut and paste, or through hyperlinks.



7. Review

7.1. The following is a little review problem

- A. Copy the Combo environment and name it Passenger
- B. Add an additional Y axis load of -980 N at the handlebar location
- C. Solve the model for only the Passenger environment
- D. Review the results.

8. Conclusions:

The true intent of this exercise was to guide you through the Mechanical Toolbar for a different type of problem with some added complexity. You are now ready to proceed with more complex problems using the MTB and full ANSYS.

As for the bike, it seems clear that under the given loading the bike is more than capable of carrying the load and then some. The material thickness of the bike could be reduced to make it lighter.